

Renovo Ultra Proofer for Vinyl Application Instructions

Please note: This product is not suitable for use on fabric soft-tops.

Vinyl Ultra Proofer is best applied to your convertible top out of direct sunlight to ensure that it doesn't dry too quickly.

1. Shake bottle thoroughly.
2. Pour Vinyl Ultra Proofer into a suitable container/bowl.
3. Start application in the centre of the soft-top and work out towards the edges with a clean 5cm/2inch paintbrush using even strokes across the whole soft-top. If preferred the Proofer can simply be rubbed into the soft-top using a sponge. Wipe excess drips from paintwork, trims and glass with a damp cloth.
4. Allow the top to dry completely before exposing it to wet weather. Drying time will vary according to atmospheric temperature but it can be as little as half an hour to a few hours.
5. Wash out brush/sponge in warm soapy water.

The soft-top is now water and stain repellent, will resist the growth of mould/mildew and is protected from harmful Ultra Violet rays.

We recommend that to ensure best possible weatherproof protection that **Vinyl Ultra Proofer** is applied every six months.